

AMBUS® Link

The intelligent M-Bus data central for configuration, operation and monitoring of M-Bus installations as a total system. The integrated web server offers a modern administration of consumption data.

Table of contents

1	Safety	2
1.1	Intended use	2
1.2	Notes on safety instructions and symbols	2
1.3	Safety instructions and precautionary measures	3
1.4	About the operation manual	3
2	Product description	4
2.1	Areas of application	4
2.2	Device design	4
2.3	Power supply	5
2.4	Interfaces	6
2.5	Memory card	7
3	Scope of delivery and accessories	7
4	Mounting	8
5	Installation	9
5.1	Connection scheme	10
5.2	M-Bus network (field level)	11
6	Commissioning	17
6.1	Switching on the AMBUS® Link	17
6.2	Operation via AMBUS® Link	18
6.3	Operation via web server	20
6.4	Configuration meter via web server	24
6.5	Creating usage units via web server	29
6.6	Configuring a reporting date reading via web server	32
6.7	Driver configuration via web server	34
6.8	Configuring a logger via web server	37
6.9	Data management via web server	45
6.10	System integration via web server	47
7	Maintenance and repair	51
8	Malfunctions and error messages	52
9	Decommissioning, disassembly and disposal	55
9.1	Decommissioning	55
9.2	Disassembly	55
9.3	Disposal	56
10	Technical data	56
10.1	Dimensions	58
11	Appendix	59
11.1	CE declaration of conformity	59
11.2	Export file type csv standard	60
11.3	Export file type csv FULL-DB	65

1 Safety

1.1 Intended use

The device AMBUS® Link is exclusively intended for the configuration, operation and monitoring of M-Bus installations as a total system.

Any improper or inappropriate use might result in a state in which the operational safety of the device cannot be guaranteed anymore. The manufacturer waives any liability for resulting damages of persons and materials.

1.2 Notes on safety instructions and symbols

The devices have been designed to fulfil modern safety requirements. They have been tested and delivered in a condition that ensures safe operation. However, improper or non-intended use of the device may result in it becoming dangerous. Please always pay attention to the safety instructions in this manual which are accompanied by the following symbols:

	<p>WARNING</p> <p>WARNING indicates an action or measure which, if performed incorrectly, can potentially cause life-threatening injuries and lead to a high safety risk.</p>
	<p>ATTENTION</p> <p>CAUTION indicates an action or measure which, if performed incorrectly, can cause minor to medium severe injuries.</p>
	<p>NOTE</p> <p>NOTE indicates a dangerous situation which might lead to material damage, if not prevented.</p>
	<p>COMMENT</p> <p>COMMENT provides helpful tips and recommendations as well as information for efficient and trouble-free operation.</p>

1.3 Safety instructions and precautionary measures

The manufacturer takes over no responsibility if the following safety instructions and precautionary measures are disregarded:

1. Changes to the device, which are implemented without prior written approval of the manufacturer, lead to the immediate termination of product liability and warranty.
2. Installation, operation, maintenance, repair and decommissioning of this device must only be performed by specialists authorised by the manufacturer, operator or owner of the device. The specialist needs to read and understand the entire installation and operation manual and is obliged to follow these instructions.
3. Control the supply voltage and information given on the type plate, before the device is installed.
4. Check all connections, settings and technical specifications of any available peripheral devices.
5. Open the housing or parts of the housing, which contain electrical or electronic components, only if the electric energy is turned off.
6. Touch no electronic components (ESD sensitivity).
7. Expose the system concerning the mechanical load (pressure, temperature, IP protection etc.) maximally to the specified classification.
8. For works concerning mechanical components of the system, the pressure in the pipe system has to be released or the temperature of the medium needs to be brought to values harmless for humans.
9. No information stated here or anywhere else releases planners, engineers, fitters and operators from their personal careful and comprehensive evaluation of the respective system configuration in terms of functionality and operational safety.
10. The local working and safety standards and statutes need to be met.

1.4 About the operation manual

The manufacturer reserves the right to change the technical details without prior notice. The newest information and versions of this operation manual are available at your local subsidiary or representation as well as on the website.

WARNING



Any liability is waived if the instructions and procedures in this manual are not followed!

NOTE



This installation instruction is intended for qualified personnel and contains thus no basic working steps. Before putting AMBUS® Link or the system into operation, the installation and operation manual needs to be read and understood completely.
Keep this manual for later reference!

2 Product description

We congratulate you for purchasing this high-quality M-Bus data central.

The device AMBUS® Link makes the configuration, operation and monitoring of M-Bus installations as a total system easier. The integrated web server serves for easy provision of your consumption data on any terminal devices or subordinate control systems.

2.1 Areas of application

AMBUS® Link is designed for technical building management and also for building services and can be used as follows:

Data concentrator


As central function of your consumption data for analysis and documentation purposes of all flow and energy meters. For easy administration the integrated web server supports on all web-enabled terminal devices the user in recording, presentation and provision of consumption data for utility cost billing or monitoring.

System integration component


With the versatile interfaces AMBUS® Link has to offer you can integrate your consumption data in the simplest way in subordinate building control systems.

2.2 Device design


AMBUS® Link is intended for control cabinet installation. The device design is defined as follows:



- ① Optical signals/lights
LED reading and LED scanning
- ② Operating elements
 -  Enter button
 -  Function button



- ① Protection covers
- ② Mounting rail protection
- ③ Mounting rail guide



- ① Status logger, operating status
- ② M-Bus slaves
- ③ IP address
- ④ Subnet mask
- ⑤ Default gateway
- ⑥ Firmware version

2.3 Power supply

For using the product outside a control cabinet the power supply can be realised as follows.

External

Manufacturer recommendations



Switching power supply UNO POWER


- Output voltage 24 VDC
- Output power 4.2 A
- Capacity 100 W

Dimensions W x H x D 55x90x84 mm


2.4 Interfaces

The data central consists of a TCP/IP interface with integrated data logger and combines the function of an M-Bus data logger and an M-Bus reading software. Thus the following software and hardware interfaces are implemented.

2.4.1. Connections




- ① RJ45 LAN connection
- ② Micro SD card slot
- ③ USB type A
- ④ USB type B
- ⑤ Terminal connection 1-15



- ① Pulse inputs terminals 1-8
- ② Power supply terminals 9-10

2.4.2. Protocols



Communication protocols

- Ethernet/LAN/WLAN
- BACnet/IP
- FTP/sFTP
- HTTP
- JSON
- CSV
- POP3

Options retrofittable via external router

- LTE
- UMTS/HSPA
- GPRS/EDGE

2.5 Memory card

The medium stores all system-specific parameters and contains parts of the operating system. It is a requirement for operating the AMBUS® Link.

Micro SD



microSDHC card Transcend Premium 400x

- | | |
|--------------------|---------|
| • Storage capacity | 32 GB |
| • Class | 10 |
| • Reading (max.) | 60 MB/s |
| • Writing (max.) | 25 MB/s |

3 Scope of delivery and accessories

The scope of delivery is described on the delivery note and the content is displayed on the packaging. Please check all components and delivered parts immediately after receiving the product. Transport damages need to be reported immediately!

- 1x AMBUS® Link
- 1x microSDHC card
- 1x brief instruction
- 3x protective covers

4 Mounting

ATTENTION


Material damage caused by neglected ambient conditions



Danger of malfunction or damage!

- Assuring accessibility for installation, operation and maintenance
- Protected, dry surroundings
- Avoid exposure to heat/sun
- Keep a safe distance to sources of electrical noise


Control cabinet mounting



1. Place recesses of the device at the top edge of the mounting rail
2. Press lightly on the AMBUS®Link
3. AMBUS®Link snaps onto the mounting rail

AMBUS®Link is firmly connected to the mounting rail

Control cabinet removal



1. Remove the piston
2. Lift AMBUS®Link up from the mounting rail

AMBUS®Link is separated from the mounting rail

5 Installation

Carefully read the following calls for action and warning information to assure a trouble-free commissioning.

WARNING

Burns and paralysis resulting in death when touching or grabbing energised system parts.

Life hazard due to electrical shock!



- Perform installation and maintenance work only when the system is off power
- Work on and with voltage shall only be performed by authorised specialists under consideration of applicable regulations
- Apply voltage only to the terminals intended
- Safeguarding by external protection elements to assure a safe switch-off in case of an error
- Install a labelled disconnecter (fuse) at an accessible location
- Use a separate fuse circuit for installation


NOTE

Terminal connections cable cross section




- Terminal connections relay, temperature sensor and M-Bus
 - Braid up to 2.5 mm²
 - Torque 0.4 Nm
- Terminal connections S0 inputs and power supply
 - Braid up to 6 mm²
 - Torque 1.3 - 1.6 Nm

5.1 Connection scheme



Terminals	Function	
Rel 1 NO/Rel 1 C	Relay 1	Normally open
Rel 2 NO/Rel 2 C	Relay 2	Normally open
PT1000 1/PT1000 C	Temperature sensor	PT1000
PT1000 2/PT1000 C	Temperature sensor	PT1000
M-BUS1-/M-BUS1+	M-BUS output 1	Master
M-BUS2-/M-BUS2+	M-BUS output 2	Master
M-BUS3-/M-BUS3+	M-BUS output 3	Master
S0 1A/S0 1B	S0 pulse input 1	Active encoder signal
S0 2A/S0 2B	S0 pulse input 2	Active encoder signal
S0 3A/S0 3B	S0 pulse input 3	Active encoder signal
S0 4A/S0 4B	S0 pulse input 4	Active encoder signal
+24V/GND	24VDC supply voltage	
RJ45	Ethernet port	
USB type A	USB interface of type A	WLAN and modems
USB type B	USB interface of type B	Level converter and maintenance


5.1.1. Power supply:



1. Assure that the power cable is voltage-free!
2. The disconnecter needs to be switched off!
3. Flip up the protective cover①
4. Loosen the terminal connection (terminal 9 (+24V DC) /10 (GND))
5. Connect the power supply ② to terminal 9 (+24V DC) /10 (GND).
6. Tighten the terminal connection
7. Close the protective cover

AMBUS® Link is ready for use

5.1.2. Attach the protective covers



1. Attach included protection cover ① with slight pressure
2. Attach included protection cover ② with slight pressure
3. Attach included protection cover ③ with slight pressure

The interfaces are protected

5.2 M-Bus network (field level)

In the following the installation of the M-Bus network with AMBUS® Link is described

ATTENTION

Material damage caused by neglected installation conditions



Danger of malfunction or damage!

- Generously dimension the main cable cross section and possibly divide it into 3 terminal groups
- Apply voltage only to the intended terminals


NOTE

High voltage drops of 5 V_{AC} on the M-Bus cables between data central and terminal node need to be avoided.



- Divide the main strand into several part strands (largest strands)
- Increase cable cross section
- Apply star shape network topology instead of chained network topology
- Apply no circular network topologies


5.2.1. Connect M-Bus meter



1. Open the protective cover ①
2. Loosen the terminal connection ② (terminals 10-15)
3. Connect M-Bus participant to terminal 10/11, 12/13 or 14/15
4. Tighten the terminal connection ②
5. Close the protective cover ①

AMBUS®Link is physically connected with the M-Bus participants

5.2.2. Connect the temperature sensor



1. Open the protective cover ①
2. Loosen the terminal connection ② (terminals 6-9)
3. Connect the temperature sensor with the terminal 6/7 or 8/9
4. Tighten the terminal connection ②
5. Close the protective cover ①

The temperature sensor is connected


COMMENT

Operating principle alarm relay 1



- Operating principle as normally open
- The following signals appear
 - Meter cannot be read out
 - Parameter error flag
 - M-Bus short circuit

5.2.3. Connect alarm relay 1



1. Open the protective cover ①
2. Loosen the terminal connection ② (terminals 1/2)
3. Connect the participant to terminal 1/2
4. Tighten the terminal connection ②
5. Close the protective cover ①

The relay output is connected


COMMENT

Operating principle alarm relay 2



- Operating principle as inverted normally open
- The following signals appear
 - Meter cannot be read out
 - Parameter error flag
 - M-Bus short circuit


5.2.4. Connect alarm relay 2



1. Open the protective cover ①
2. Loosen the terminal connection ② (terminals 3/4)
3. Connect the participant to terminal 3/4
4. Tighten the terminal connection ②
5. Close the protective cover ①

The relay output is connected


5.2.5. Connect pulse inputs



1. Open the protective cover ①
2. Loosen the terminal connection ② (terminals 1-8)
3. Connect pulser to terminal 1/2, 3/4, 5/6 or 7/8
4. Tighten the terminal connection ②
5. Close the protective cover ①

The pulser is connected


5.2.6. Connect USB type A



1. Plug the USB type A into the intended port

The external USB device is connected.


5.2.7. Connect USB type B



1. Plug the USB type B into the intended port

The external USB device is connected.

5.2.8. Connect network cable RJ45



1. Plug the RJ-45 connector into the intended port

The network cable is connected


NOTE

In case of improper handling the microSD card falls into the housing between the slot and the surface.



- Control the exact positioning of the microSD card before inserting it
- Use a slotted screwdriver to insert it.

5.2.9. Inserting a mini SD card



1. Insert the microSD card centred into the intended port
2. Press the microSD card with slight pressure over the snap-in point
3. The microSD card snaps in the port

The microSD card is connected.

6 Commissioning

AMBUS® Link can be commissioned in two ways, which are described in the following chapter.

6.1 Switching on the AMBUS® Link

WARNING

Burns and paralysis resulting in death when touching or grabbing energised system parts.


Life hazard due to electrical shock!



- Perform installation and maintenance work only when the system is off power
- Work on and with voltage shall only be performed by authorised specialists under consideration of applicable regulations
- Apply voltage only to the intended terminals
- Protection by external protection elements to assure a safe switch-off in case of an error
- Install a labelled disconnecter (fuse) at an accessible location

Use a separate fuse circuit for installation

Switching AMBUS® Link on



1. Start the supply via the disconnecter
2. AMBUS® Link starts
3. The reading and scanning LEDs are "slightly" glowing
4. The display is flashing after 30 sec.

AMBUS® Link is ready for use

6.2 Operation via AMBUS® Link

COMMENT



The delivery state of the network configuration ex works

- DHCP is activated, IP address is automatically obtained
- DHCP is deactivated by manual entry of the network parameters
 - Activating DHCP by entering zeros for all network parameters


COMMENT



Functionality of the secondary search

- The search via secondary address is conducted as reverse search

6.2.1. Quick commissioning M-Bus network



1. Hold the  button for more than 5 sec.
2. M-Bus meter search is started via secondary address
3. The reading and scanning LEDs are glowing "brightly"
4. The operating mode reports SCAN
5. Scanned meters are shown on the display (slaves)

All meters have been read in


COMMENT



Finalising the quick configuration of the network parameters

- The set parameters are activated after the configuration has been finished
- The configuration is finished after de-selecting the last digit


6.2.2. Quick configuration network parameters



1. Hold the  button for more than 2 sec. first position at IP is selected and configurable
2. When pressing the  button the marked digit increases by one (0-9)
3. The  button confirms the set digit and jumps to the next

IP address, subnet mask and default gateway are set, the network is configured

6.2.3. Restart AMBUS® Link



1. Hold the  button and  button together longer than 5 sec.
2. After releasing the buttons a restart is performed

AMBUS® Link restarts and the settings remain preserved

6.3 Operation via web server

COMMENT



Operation

-  Button for home screen view
- Automatic logout after 10 minutes without operation

COMMENT



Role rights

- The rights of each role are fixed and cannot be changed
- Administrator «all rights»
- Standard user «read rights» cannot make changes to the system
- In the delivery state a user is predefined
 - Admin (administrator role)

COMMENT



Reachability of the web server concerning the firewall

- The communication takes place via TCP, HTTP and websocket
- Port 80 is the communication port


COMMENT



Explanation of the connection indicator

- connected (connection established)
- connecting (connection in establishment)
- not connected (connection failed)

6.3.1. Language settings



1. Change language
 - German
 - English
 - French

Language is loaded

COMMENT

User administration, password



- Any number of users can be registered in the system
- Username minimum length 3 characters
- Password minimum length 3 characters
- Each logged in user can change their personal password

- The standard password for the «admin» user is 123

It is recommended to change the standard password!

6.3.2. Create a user profile



1. Enter a username
2. Select role
3. Enter password
4. Enter password again
5. Press **Apply**

The user is created

COMMENT



User management as administrator

- A role change for other users is possible
- A password change for other users is possible

6.3.3. Change a user profile



1. Select a user
2. Change role
3. Press **Apply** for role change
4. Enter password
5. Enter password again
6. Press **Apply** for password change

The settings are changed

COMMENT



User management as administrator

- Deleting other users is possible

6.3.4. Deleting a user profile



1. Select a user
2. Press **Delete user**
3. Confirm the prompt

The user is deleted


6.3.5. Changing the personal password



1. Enter current password
2. Enter new password
3. Enter new password again
4. Press **Apply**

The password is changed


6.3.6. Basic settings



1. Enter name and location
2. Choose time zone
3. Press **Save**

Basic settings are defined and displayed in the banner

6.3.7. Setting date and time



1. Set date and time
2. Press

Date and time are set and displayed in the footer

6.4 Configuration meter via web server

COMMENT

Registration procedure of M-Bus participants



- Network search of connected M-Bus participants
 - All meters in the M-Bus network can be registered
- Offline registration of M-Bus participants
 - Configuration of the M-Bus network without M-Bus participants
 - Registration of participants after installation in the M-Bus network and first-time network reading


COMMENT

Restrictions of the address range



- When searching with the primary address the range can be freely selected between 1-250


6.4.1. Search all meters



1. Choose Baud rate
2. Start scan via Secondary address or via Primary address

The meters in the M-Bus network are registered



6.4.2. Recording individual meters



1. Choose recording Prim or Sec
2. Set Baud rate
3. Enter the primary and secondary address of the meter
4. Save Confirm

The individual meter is saved

6.4.3. Check recorded meters



1. All registered meters are listed in a table
2. Check status
 - Found meters - successfully read
 - Existing meters - M-Bus alarm
 - Existing meters - Reading error
 - Missing meters - not yet read out

All meters are available


COMMENT



Definition of the global reading cycle

- The reading cycle is set with «15 min» as a standard
- The reading cycle can be set between 10 sec. - 48h
- The reading cycle is dependent on the entire M-Bus network

6.4.4. Configuring a global reading cycle



1. **15 min** Choose reading cycle
2. Press **Save**

All meters are cyclically read out

COMMENT

M-Bus protocol-specific parameters

- M-Bus protocol-specific values can be overmodulated via AMBUS® Link
 - Meter type
 - SND_NKE
 - Application reset (including subcodes)
 - Designation
 - Unit
 - Decimal place
 - Phase (phase number for electricity meters)
 - Tariff (tariff number for meters with several counting modules for different tariffs)
 - Mon. (Month number of a record date meter value)



Single meter configuration for Aquametro and third party meters

- Easy meter configuration for individual meters
- Individual configurations can be saved as templates and applied for all identical meters
- As a standard for each M-Bus request an SND-NKE and an application reset with subcode «0» are set. The function can be deactivated by using the checkbox SND_NKE/App. Reset Aus App. Reset Subcode
- Application reset subcodes can be entered into the field
- Meter-specific reading cycles overmodulate global reading cycles

COMMENT

Correct the decimal places for value units

- For decimal places to the left «factor 1000»
- For decimal places to the right «factor 0.001»




NOTE

Parameter changes for M-Bus participants might lead to wrong consumption data



- In case of manipulated meters (M-Bus), the meters need to be newly registered (registration)



6.4.5. Editing meter details



1. State name, location, cost centre and comment
2.  choose meter type
3. Choose recording Prim or Sec
4. Choose reading cycle 
5. Choose Baud rate
6. Tick battery operation Battery
7. Press 
8. Confirm the designation 
9. Mark the designation
10. Choose the unit 
11. State phase, divisor, tariff
12. Press 

The individual meter configuration is finished

6.4.6. Deleting a meter



1. Select all or individual meters
2. Press 
3.  The data is updated

All/individual meters are deleted

6.5 Creating usage units via web server

In the following chapter the creation of user-defined, organisational units (usage units) for administration of M-Bus participants is described


COMMENT



Administration of usage units

- Formation of organisational units
- User-specific meter group allocation

6.5.1. Defining a usage units



Station ID: (1105 Staves)
13.01.2017 - 14:59:57
SW: 07102 FW 1.1.0306L1

Name	Location	Mbus Voltage	Mbus Current	Temperature 1	Temperature 2
		39.93 V	126 mA	32.5 °C	32.8 °C

Buttons: New, Add

Name	Description	Details
	Example	

Buttons: Add

CREATE NEW USER UNIT

Name: Description:

Buttons: Add


Station ID: (1105 Staves)
17.01.2017 - 14:59:31
SW: 07102 FW 1.1.0306L1

1. Press **New** to create a usage unit

1. Enter the name of the usage unit
2. Enter a description
3. Press **Add**

The usage unit is created



6.5.2. Deleting a usage unit



1. Select a usage unit
2. Press **Delete**

The usage unit is deleted

6.5.3. Allocating a meter to a usage unit





1. Select a usage unit
2. Press **Details**

1. Press **Add**
2. Select the meter for the usage unit
3. Press **Apply**

The meter is now allocated to a usage unit


6.5.4. Deleting a meter from a usage unit



1. Select a usage unit
2. Press **Details**
3. Select the meter of the usage unit
4. Press **Remove**

The meters are now deleted from the usage unit



6.5.5. Add a user for a usage unit



1. Select a usage unit
2. Press **Details**
3. Press **Add**
4. Select the user for the usage unit
5. Press **Apply**

The user is now allocated to the usage unit

6.5.6. Delete a user from a usage unit



1. Select a usage unit
2. Press **Details**
3. Select the user for the usage unit
4. Press **Remove**

The user is now deleted from the usage unit

6.6 Configuring a reporting date reading via web server


COMMENT

Configuration of reporting date reading



- Use numeric input for month, day and hour
 - Month (1 -12)
 - Day (1-31)
 - Hour (0 -23)
- Report date data available in the export file


6.6.1. Creating a reporting date



1. Press **Add**
2. Enter month, day and hour
3. Confirm the last day **On**
4. Actively press **On**

The reporting date reading is set for the last day of the month and the specified reporting date

6.6.2. Deleting a reporting date



1. Mark the line
2. Press **Delete**

The reporting date reading is deleted

6.7 Driver configuration via web server

COMMENT

Driver configuration for Aquametro and third party meters

- Easy driver configuration for all meters
- M-Bus protocol-specific values can be overmodulated via AMBUS® Link
 - Designation
 - Unit
 - Decimal place
 - Phase (phase number for electricity meters)
 - Tariff (tariff number for meters with several counting modules for different tariffs)
 - Mon. (Month number of a record date meter value)
- Templates are applied on the basis of the following criteria
 - Manufacturer code
 - Version byte
 - Number of data records
- Driver templates can be exported and sent to Aquametro
 - Inclusion in third party meter library
 - Export file in JSON format
 - The exported file is saved in the download folder of the web browser



COMMENT

Correct the decimal places for value units

- For decimal places to the left «factor 1000»
- For decimal places to the right «factor 0.001»




NOTE

Parameter changes for M-Bus participants might lead to wrong consumption data

- In case of manipulated meters (M-Bus), the meters need to be newly registered (registration)




6.7.1. Creating a driver template



1. Select a meter
2. Press **Details**
3. Press **Save as template**

The driver template for meters is created


6.7.2. Editing a driver template



1. Select a driver template
2. Press **Details**
3. Enter the device designation
4. Choose the device designation from the value definitions
5. Set the target unit
6. Enter the phase and divisor (if required)
7. Mon. enter (if required)
8. Enter tariff (if required)
9. Press **Save**

Update and save the driver template


6.7.3. Apply driver template to meter



1. Select a driver template
2. Press **Details**
3. Press **Apply**

All meters with the same manufacturer code are configured according to the driver template


6.7.4. Export driver template



1. Select a driver template
2. Enter a file name
3. Press **Export**
4. Execute save file as

The meter driver template is exported


6.7.5. Import driver template



1. Press **Select File**
2. Press **Import**
3. **Note**
Backup import successful
OK
4. Press **OK**

Import driver template

6.7.6. Delete driver template



1. Select a driver template
2. Press **Delete**

The reporting date reading is deleted

6.8 Configuring a logger via web server

COMMENT

Correctly choose reading times



- Reading times depend on the circumstances and the dimensioning of the M-Bus network
- The reading cycle applies for the entire M-Bus network
- For 100 or more meters at least 2 min per reading
- For 250 meters at least 5 min per reading


COMMENT



Define network parameters via DHCP

- DHCP needs to be activated at the router
- Set that the IP address is automatically allocated from the DHCP server

6.8.1. Network settings



1. Enter IP address of the AMBUS® Link
2. Enter subnet mask
3. Enter the gateway of the router
4. Enter the DNS server address 1 and 2 on demand
5. Activate DHCP on demand
6. Press

Established connection with AMBUS® Link


COMMENT



Requirements for correct logging of consumption data

- The system time is correctly set (see basic settings)
- AMBUS® Link is working with UTC time
- The UTC time is calculated with the defined local time and time zone
- The system time is defined via an NTP server
 - e.g. metasntp11.admin.ch


6.8.2. Set up an NTP time server



1. Define the NTP server
2. Press

The system time is synchronised with the defined server



6.8.3. Logging the temperature sensors



1. Mark the line
2. Activate

The temperature sensor is logged

6.8.4. Logging the S0 inputs



1. Mark the line
2. Enter the starting value
3. Activate

S0 input is logged

COMMENT

Using the level converter



- Using the level converter via USB type B interface
- Setting «Default» complies with 2400 Baud
- When the level converter is activated the status changes
 - to web server «Level converter RS232» is on
 - to AMBUS® Link «[< - - >]» is on
- The logger function is deactivated in the level converter operation

6.8.5. Switching on the level converter



1. Choose the Baud rate of the meter

2. Activate  the level converter
3. Press 

The level converter is activated



COMMENT

Filtering the status messages

- Status details
 - 0 - After switching on the device, start process "logger"
 - 1 - M-Bus overcurrent
 - 2 - Start cloud upload
 - 3 - Error cloud upload
 - 4 - Cloud upload successfully completed
 - 5 - Start FTP/sFTP upload
 - 6 - Error FTP/sFTP upload
 - 7 - FTP/sFTP upload successfully completed
 - 8 - Meter (serial number), reading failed
 - 9 - Email transmission failed
 - 10 - Error on a meter
- It is recommended to regularly delete the status messages to prevent long updating times.



6.8.6. Status messages





1. Enter status number



2. The data is updated
3. Press **refresh** for actualisation

Status information is displayed

6.8.7. Message type selection





1. Select a message
 - a. Error
 - b. Warning
 - c. Info



2. The data is updated
3. Press **refresh** for actualisation

Message type selected

6.8.8. Delete status messages



1. Press **Delete all**

All status messages are deleted


COMMENT

Configuration email



- Several email addresses possible by using a semicolon as separator
- Sending of
 - M-Bus alarm (warning)
 - Reading error (error)

6.8.9. Sending alarms via email



1. Enter email server and port
2. Enter name and email address of the sender
3. Enter email address of the recipient
4. Select connection type
 - TCP
 - SSL
 - TLS
5. Select login
 - Login
 - Plain
6. Adjust timeouts
7. Enter username and password
8. On/Off Activate/deactivate function
9. Press **Save**

Alarms have been sent via email


COMMENT

Configuration logger



- Backup file
 - Export file in JSON format
 - The exported file is saved in the download folder of the web browser
- Contains complete logger configuration
 - Without meter

6.8.10. Export logger configuration




1. Press **Download** for saving the current logger configuration

2.  Data is downloaded

Data is exported

6.8.11. Import logger configuration



1. Press **Select File** (format JSON)

2. Select file
3. Configuration_Name_28_11_2016_10_2.json File is displayed

4. Press **Import**
5.  Backup is imported

Logger configuration is imported

NOTE



Failed firmware updates might lead to a loss of data

- Perform configuration logger «Backup» (6.8.10)

COMMENT

Install firmware updates



- Updating individual functional units
 - M-Bus logger
 - BACnet/IP
 - Connect
 - Websocket
 - Web server
- Package update as format «*.ipk»
- Multiple selection for package updates possible
- Fail-safe firmware update with intermediate storage

6.8.12. Firmware package update



1. Press **Select File**
2. Select file
3. Press **Upload**
4.  File is uploaded
5. Data is displayed in table
6. Repeat step 1-4 for additional files
7. **Install all** Updates are installed
8. Execute firmware package overview (see 6.8.13)
9. Press **Delete all**

Updates have been installed

COMMENT

Installed firmware packages



- View of all firmware packages with time stamp and status
- Control of successful installations with the time stamp
- The update process might take several minutes

6.8.13. Firmware package overview




1. Press **SW-Package info update**

The overview of installed updates is refreshed

6.9 Data management via web server

6.9.1. Overview of meter statuses



1. Select **Details** of a meter


The table with current meter statuses is displayed

COMMENT



The function "Update" reads the current data of the last reading process from a database. No M-Bus reading is performed.

6.9.2. Viewing meter statuses



6.9.3. Print/save charts



1. Select **CALEC ST** (with menu icon) for selecting a meter
2. Press **Refresh**

Data of selected meters are shown

1. Select **Chart** for diagram view
2. Select **Monday, 13.02.2017** (with menu icon) to choose starting time

Meter statuses are displayed from starting time. Comparison with the previous day, week, month or year is displayed



1. Select **Chart** for diagram view
2. Select **Monday, 13.02.2017** (with menu icon) to choose starting time
3. Press **Printer** (with menu icon)
4. Select **Print or Save**

Charts are saved or printed

6.10 System integration via web server

COMMENT

Data export

- Data can be exported manually or via FTP/sFTP
- For a larger time period the process takes several minutes
- Export type CSV
 - Option «Standard» see chapter 11.2
 - Option «Standard» see chapter 11.3
 - Enter separator
- The exported files are saved in a compressed ZIP archive (DataExport.zip) in the download folder of the web browser.
- FTP files are saved after each reading cycle in the indicated directory (push process)





Integration of a cloud solution

- ISO 50001 certified energy management software solution
- Please contact your Aquametro contact person

Integration via BACnet/IP

- All registered M-Bus meters are also available as BACnet objects
- AMBUS® Link is BBMD-capable
- At maximum 16 BBMD servers can be set up
- The M-Bus can be permanently read out
 - Permanent reading: It is not waited for the next reading cycle. As soon as the reading is finished the next query is started

6.10.1. Export meter data



1. Select individual meters or all meters
2. Select a time period
3. Choose a medium (optional)
4. Select export type
5. Select options
6. Select a separator
7. Press


Export file is generated and saved in the ZIP archive

COMMENT



FTP upload File path
 10-46110815-20161122102732
 ID-Secondary address-YearMonthDayHourMinuteSecond
 ID : Internal AMBUS Link identification number (configuration meter 6.4.5)


6.10.2. Meter data upload via FTP /sFTP



1. Define information about FTP/sFTP server
 - Server address
 - Port
 - Username
 - Password
 - Path
2. On Activate/deactivate upload
3. Activate/deactivate SSL
4. Select export type
5. Select a separator
6. Select options
7. Select language
8. Press
9. Press (manual upload)

Data is pushed to the FTP/sFTP server


6.10.3. Upload of meter data via cloud



1. Specify information about the cloud server
 - Server address
 - Port
 - ID
2. On Activate/deactivate upload
3. Press **Save**
4. **Select pem**
5. Press **Upload** (manual upload)
6. **Delete pem**

Data is pushed in the cloud


6.10.4. Switch on BACnet/IP



1. Define BACnet settings
 - D-Net number
 - Port number
 - Device instance number
2. Activate/deactivate BBMD on
3. Activate/deactivate BACnet on
4. Activate/deactivate M-Bus continuous reading on
5. Press **Save**

BACnet/IP is switched on

6.10.5. Define a BACnet BBMD server




1. Define BACnet BBMD settings

- IP address
- Subnet mask
- UDP port

2. Press **Add**

BACnet BBMD server has been defined

6.10.6. Delete BACnet BBMD server



1. Select server

2. Press **Delete**

BACnet BBMD server is deleted

7 Maintenance and repair

The product requires no maintenance. Cleaning shall only be performed with a moistened cloth. No solvents or other aggressive agents shall be applied.

WARNING

Risk of death by electric shock from live cables and parts.







Risk of electric shock!

1. Perform installation and maintenance work only when the system is off power.
2. Work on and with voltage shall only be performed by authorised specialists under consideration of applicable regulations.
3. For connections to the power supply only the intended terminals shall be used.



8 Malfunctions and error messages

Symptom	Reason	Correction
LEDs are not glowing	<ul style="list-style-type: none"> • No supply available 	Check power supply incl. supply isolation terminal according to installation manual
AMBUS® Link finds no meter	<ul style="list-style-type: none"> • No or wrongly installed meters 	Check meter installations
	<ul style="list-style-type: none"> • Wrong Baud rate selected 	Check the selected Baud rate according to chapter 6.4.1
AMBUS® Link finds not all meters	<ul style="list-style-type: none"> • Addresses have been assigned twice 	Control M-Bus network with a suitable M-Bus tool for bus numbers, which have been assigned twice
	<ul style="list-style-type: none"> • Meter with wrong Baud rate 	Control the Baud rate at the meter, select a lower Baud rate at the meter, if possible.
The operating status shows «OFF» during startup and «MMC Missing» appears on the display	<ul style="list-style-type: none"> • No mini SD card in the slot. 	<ul style="list-style-type: none"> • Disconnect AMBUS® Link from the power supply • Enter a microSD card in the respective slot • Switch AMBUS® Link on


Login

 <p>Notification Incorrect username or password! OK</p>	<ul style="list-style-type: none">• Wrong username or password	<ul style="list-style-type: none">• Enter correct username and password
<h2>Create a user profile</h2>		
 <p>Note Password repeat doesn't match! OK</p>	<ul style="list-style-type: none">• The current password is not corresponding with the repeated password	<ul style="list-style-type: none">• Enter the password correctly again
 <p>Note Password too short! OK</p>	<ul style="list-style-type: none">• The minimum length of 3 characters has not been complied with	<ul style="list-style-type: none">• Enter a password with at least 3 characters
 <p>Note No role selected! OK</p>	<ul style="list-style-type: none">• The details have not been filled out completely.	<ul style="list-style-type: none">• Repeat the registration and fill out all details


Changing the password

	<ul style="list-style-type: none"> • The current password is not corresponding with the repeatedly entered password 	<ul style="list-style-type: none"> • Enter the password correctly again
	<ul style="list-style-type: none"> • The minimum length of 3 characters has not been complied with 	<ul style="list-style-type: none"> • Enter a password with at least 3 characters

Search all meters

	<ul style="list-style-type: none"> • Primary address range set too small 	<ul style="list-style-type: none"> • Set the primary address range generously
---	---	--

Define BACnet/IP BBMD server

	<ul style="list-style-type: none"> • A BBMD server with an identical IP address already exists. 	<ul style="list-style-type: none"> • Select new, unique IP address
---	--	---

9 Decommissioning, disassembly and disposal

WARNING


Risk of death by electric shock from live cables and parts.



Risk of electric shock!

1. Perform installation and maintenance work only when the system is off power.
2. Work on and with voltage shall only be performed by authorised specialists under consideration of applicable regulations.
3. For connections to the power supply only the intended terminals shall be used.

9.1 Decommissioning




1. Disconnect from all sources of energy
2. Remove all cables and connections from the device
3. Remove the device from the system

AMBUS® Link is out of service

9.2 Disassembly

Control cabinet removal



1. Remove the piston
2. Lift AMBUS®Link up from the mounting rail

AMBUS®Link is separated from the mounting rail

9.3 Disposal

At the end of the life cycle this product must be recycled or disposed according to the local provisions.

Remove batteries and accumulators and dispose them separately.



The separate collection and recycling of old devices helps to preserve natural resources and assures that they are disposed in a way that the protection of the environment and nature is assured.

10 Technical data

Basic data	
Power supply:	24 VDC
Power consumption	Max. 1A
Temperature range	0 - 55°C
Display	LCD display with background lighting (128x64 dots)
Weight	Approx. 400g
Installation	35mm DIN rail
Housing:	Polycarbonate, recyclable, non-flammable
Evaluation	Web server/diagram
Data export	As JSON or CSV file
Data memory	Micro SD card (needs to have more than 32 GB free space available)
Firmware update	Yes, is possible
Configuration	Local and remote configuration with web browser
Inputs	3x M-Bus 2x temperature PT1000 (-20°C to +100°C) 4x S0

Outputs	2 x relay
Interfaces	1x Ethernet 10/100 Base RJ45
	1x USB type A
	1x USB type B



M-Bus	
Baud rates	300, 600, 1200, 2400, 4800, 9600
Compatibility	Heat, water, gas and electricity meter with M-Bus according to EN 13757-2,-3 (former EN1434-3)
Level converter	Integrated Transparently operatable via USB type B
M-Bus closed current	Max. 375mA (250 x 1.5mA)
Number of M-Bus slaves	Max. 250 (see order information)
Galvanic separation	Yes
Short-circuit protection	Yes
Overload protection	Yes

BACnet/IP	
Specifications	All M-Bus meters registered on AMBUS® Link are automatically translated into BACnet/IP objects.
BBMD	Yes
Protocol Implementation Conformance Statement	The PICS document can be found on our website at: www.aquametro.com/ambuslink

Approvals and norms

Safety	CE-declaration
EMC metering	EN 61000-6.2
Interference immunity	EN 61000-6-3
M-Bus norm	EN 13757-2,-3
Energy management	Suitable for ISO 50001
BACnet	Certified

10.1 Dimensions



Alle Dimensionen
in mm

5 TE Gehäuse
5 Module Case

11 Appendix

11.1 CE declaration of conformity

Konformitätserklärung Declaration of conformity Déclaration de conformité Dichiarazione di conformità		 <small>everything that counts</small>
AQUAMETRO AG, Ringstrasse 75, CH-4106 Therwil		
erklärt, dass das Produkt declares that the product déclare que le produit dichiara che i prodotti	Datenzentrale data center centre de données data center	AMBUS® Link
mit den Vorschriften folgender Richtlinien übereinstimmt : <i>conforms with the regulations of the following European Council Directives :</i> <i>est conforme aux prescriptions et directives Européennes suivantes :</i> <i>è conforme alle seguenti prescrizioni e direttive Europee :</i>		
CE-Konformität		
Richtlinie Directive Directive Direttiva	Beurteilungsverfahren Method of assessment Méthode d'évaluation Metodo di valutazione	Benannte Stelle Notified body Organisme notifié Organizzazione notificata
CE EMC 2014/30/EU EMV Richtlinie EMC directive Directive CEM Direttiva CEM	Report: E2159-05-16	QUINEL AG (STS 0037) CH-6035 Perlen
Weitere Konformitäten		
Richtlinie Directive Directive Direttiva	Beurteilungsverfahren Method of assessment Méthode d'évaluation Metodo di valutazione	Benannte Stelle Notified body Organisme notifié Organizzazione notificata
Therwil, 30.01.2017	 Thomas Bisang Leiter Qualitätsmanagement Head Quality Management Responsable gestion de qualité Direttore gestione qualità	 Remo Bucheli Produkt Management Product Management Management des produits Management del prodotto

11.2 Export file type csv standard

Date/Time(UTC)	PrimaryAddress	Serial	ManufacturerId	Version
26.01.2017 16:12		10	4800181 AMT	192
26.01.2017 16:27		10	4800181 AMT	192
26.01.2017 16:43		10	4800181 AMT	192

Medium	Energy	Energy_Einheit	Volume	Volume_Einheit
Heat (outlet)	2709840000 Wh		43240.1 m³	
Heat (outlet)	2709870000 Wh		43240.5 m³	
Heat (outlet)	2709890000 Wh		43240.8 m³	

Units for H. C. A.	Units for H. C. A._Einheit	Units for H. C. A.	Units for H. C. A._Einheit	Power
0		0		86269.3
0		0		86212.8
0		0		86216.5

Power_Einheit	Volume flow	Volume flow_Einheit	Flow temperature	Flow temperature_Einheit
W	1.37621 m³/h		131.759 Degree C	
W	1.37584 m³/h		131.766 Degree C	
W	1.37555 m³/h		131.759 Degree C	

Return temperature	Return temperature_Einheit	Temperature difference	Temperature difference_Einheit	Energy (per kelvinliter)
76.9198 Degree C		54.8394 K		1.14265
76.9266 Degree C		54.8395 K		1.14264
76.9061 Degree C		54.8531 K		1.14264

Energy (per kelvinliter)_Einheit	Mass (per liter)	Mass (per liter)_Einheit	On time	On time_Einheit
Wh	0.974371 kg		45865 h	
Wh	0.974366 kg		45866 h	
Wh	0.974362 kg		45866 h	

On time / VT=3 (Error)	On time / VT=3 (Error)_Einheit	Volume (per input pulse ch. 0)	Volume (per input pulse ch. 0)_Einheit	Units for H. C. A. (per input pulse ch. 0)
0 h		0.00101 m³		1
0 h		0.00101 m³		1
0 h		0.00101 m³		1

Units for H. C. A. (per input pulse ch. 0)_Einheit	Units for H. C. A. (per input pulse ch. 0)	Units for H. C. A. (per input pulse ch. 0)_Einheit	Address	Address_Einheit
	1		10	None
	1		10	None
	1		10	None

Fabrication	Fabrication_Einheit	Timestamp (future value) / Monat 1	Timestamp (future value) / Monat 1_Einheit	Timestamp (future value) / Monat 2
4800181	None	2024246144	UTC	2040143744
4800181	None	2024246144	UTC	2040143744
4800181	None	2024246144	UTC	2040143744

Timestamp (future value) / Monat 2_Einheit	Customer	Customer_Einheit	Metrology (firmware) version	Metrology (firmware) version_Einheit
UTC		0 None	10500	None
UTC		0 None	10500	None
UTC		0 None	10500	None

Hardware version	Hardware version_Einheit
	0 None
	0 None
	0 None

Date/time (UTC)	Coordinated world time
PrimaryAddress	Primary address
Serial	Secondary address/serial number
ManufacturedId	Manufacturer identification number according to M-Bus
Version	M-Bus version byte
Medium	Medium
Energy	Energy value
Energy unit	Unit of the energy value
Volume	Volume
Volume unit	Unit of the volume

Units for H.C.A.	Heat Cost Allocator allocation formula
Units for H.C.A. Unit	No unit ("none")
Units for H.C.A.	Heat Cost Allocator allocation formula
Units for H.C.A. Unit	No unit ("none")
Power	Power
Power unit	Unit of the power
Volume flow	Flow value
Volume flow_unit	Unit of the flow
Flow temperature	Flow temperature
Flow temperature_unit	Unit of the flow temperature
Return temperature	Return temperature
Return temperature_unit	Unit of the return temperature
Temperature difference	Temperature difference
Temperature difference_unit	Unit of the temperature difference
Energy (per kelvin litre)	Correction factor
Energy (per kelvin litre)_unit	Unit of the correction factor
Mass (per litre)	Density

On time	Operating hours
On time_unit	Unit of the operating hours
On time/VT=3 (error)	Error hours
On time/VT=3 (error)_unit	Unit of the error hours
Volume (per input pulse ch. 0)	Pulse value
Volume (per input pulse ch. 0)_unit	Unit of the pulse value
Units for H.C.A. (per input pulse ch. 0)	Pulse value auxiliary meter 1
Units for H.C.A. (per input pulse ch. 0)_unit	No unit ("none")
Units for H.C.A. (per input pulse ch. 0)	Pulse value auxiliary meter 2
Units for H.C.A. (per input pulse ch. 0)_unit	No unit ("none")
Address	Primary address
Address_unit	No unit ("none")
Fabrication	Fabrication number
Fabrication_unit	No unit ("none")
Time stamp (future value)/month 1	Reporting date 1
Time stamp (future value)/month 1_unit	Unit of the reporting date

Time stamp (future value)/month 2	Reporting date 2
Time stamp (future value)/month 2_unit	Unit of the reporting date
Customer	Customer text field
Customer_unit	Text
Metrology (firmware) version	Firmware version
Metrology (firmware) version_unit	No unit ("none")
Hardware version	Hardware version
Hardware version_unit	No unit ("none")

11.3 Export file type csv FULL-DB

Device.Id	AddressMode	PrimaryAddress	ManufacturerId	Serial	Version	Medium	Device.Active	ReadoutCycle	BaudRate
29	0	10	AMT	4800181	192	Heat (outlet)	-1	0	2400
29	0	10	AMT	4800181	192	Heat (outlet)	-1	0	2400
29	0	10	AMT	4800181	192	Heat (outlet)	-1	0	2400

BACNetDevInstNumber	Name	Site	CostUnit	CommentStr	LoggerLastReadoutOk	LoggerReadoutState	LoggerReadoutCycle	MediumGroup	Battery
4194077	CALEC ST				1485440274	1	0	3	0
4194077	CALEC ST				1485440274	1	0	3	0
4194077	CALEC ST				1485440274	1	0	3	0

Position	DescriptionStr	UnitStr	ScalePower	ScaleMantissa	EncodeType	ValueType	StorageNum	Tariff	ValueDesc.Active
0	Energy	Wh	0	0	0	0	0	0	-1
0	Energy	Wh	0	0	0	0	0	0	-1
0	Energy	Wh	0	0	0	0	0	0	-1

LoggerLastValue	CfgDescription	CfgUnit	CfgPhase	CfgFactor	CfgStorageNum	CfgTariff	TimeStamp	Val1	ValueDesc.Id
2709680000		0	0	0	0	0	1485303093	2706390000	3438
2709680000		0	0	0	0	0	1485304020	2706420000	3438
2709680000		0	0	0	0	0	1485304945	2706440000	3438

Explanation CSV export (FullDB)

Device .ID	Internal AMBUS Link identification number (configuration meter)
AddressMode	Primary switch - secondary reading
PrimaryAddress	Primary address
ManufacturedId	Manufacturer identification number according to M-Bus
Serial	Secondary address/serial number
Version	M-Bus version byte

Medium	Medium
Device.Active	<p>Defines if a meter is logged during reading and transferred with the report. Value 1: Meter is logged and transferred</p> <p>Value 0: Meter is not transferred</p> <p>Value -1: not configured</p>
ReadoutCycle	Meter-specific reading cycle (only configuration, without reading)
Baud rate	Baud rate
BACNetDevInstNumber	BACnet device instance number
Name	Name
Site	Location
CostUnit	Cost centre
CommentStr	Comment
LoggerLastReadoutOk	Last successfully readout (UNIX time stamp)
LoggerReadoutState	<p>Status of readout</p> <p>Value 0: not defined</p> <p>Value 1: OK</p> <p>Value 2: Error</p>
LoggerReadoutCycle	Individual reading cycle (position in dropdown)

MediumGroup	Individual meter type (value from dropdown)
Battery	Battery flag
Position	N/A
DescriptionStr	M-Bus parameter name
UnitStr	M-Bus unit
ScalePower	Scale factor for the integrated reading value
ScaleMantissa	Scale factor (mantissa)
EncodeType	<p>Encoding type of the meter in the M-Bus package (e.g.: INT8, INT32, BCD8 or VARIABLEDATA).</p> <p>Within the logging integer-based meter values are listed as numbers, text-based meter values as text and binary data as text-based hexadecimal characters.</p>
ValueType	<p>Value MAXIMUM: Meter value is a maximum value over a timespan.</p> <p>Value MINIMUM: Meter value is a minimum value over a timespan.</p> <p>Value ERRORSTATE: Meter value is in error status.</p> <p>Value INSTANTANEOUS: Meter value is an instantaneous value.</p>
StorageNum	<p>The storage number of the meter value defined by the meter.</p> <p>Value 0 defines that the associated meter value for the current time has been recorded.</p> <p>A value unequal 0 defines that a meter value at a specific time (defined by the meter manufacturer) has been recorded.</p>

	An associated time stamp is also included in the CSV log (time stamp).
Tariff	Tariff
ValueDesc.Active	N/A
LoggerLastValue	Last value
CfgDescription	Designation (manual from template)
CfgUnit	Unit (manual from template)
CfgPhase	Phase (manual from template)
CfgFactor	Factor
CfgStorageNum	Storage number (transmitted by meter)
CfgTariff	Tariff (manual from template)
TimeStamp	Time stamp
Val1	Value
ValueDesc.Id	Value identification number

