

Lavish Lashes Heat Sterilizer Instructions

How to Operate:

- 1 Place the sterilizer on a stable flat surface
- 2 Open the black lid and place small beads into the tank, reaching no more than 80% of its depth.
- 3 Plug in the unit, turn on the unit by pressing the switch overlay from “O” (off) to “I” for on. The switch will turn red to indicate heat and power is being applied.
- 4 After 10-12 minutes of heating time, a green indicator light will illuminate to signal the sterilizer being adequate temperature for sterilization.
- 5 Place the end of your instruments or tools vertically in the tank into the beads.
- 6 After 20-30 seconds of sterilizing time, the tools are ready to take out. Please ensure that you use heat resistant gloves.
- 7 When the temperature of the tank reaches a maximum temperature of 392°F, the red illuminated night will turn off and the sterilizer will stop heating.

Cleaning:

- Clean the product with alcohol and a cloth or cotton ball.
- The product should always be kept in dry places.



Warnings:

- DO NOT plug in before identifying if the voltages of the product and electrical source are congruent.
- Keep out of reach of children.
- Small beads are not edible.
- NEVER use the product when there are no quartz beads in the tank.
- It is important to keep the unit unplugged and make sure it is cooled for 20 minutes before disinfecting.
- NEVER clean the product with liquid other than alcohol.